

FLOODLINE Smart FlexiPad

The Andel Smart FlexiPad Sensors have been specifically designed for installing in narrow voids such as underneath dishwashers, washing machines, sinks, baths, and showers.



The Smart FlexiPad will detect a water leak on any part of its surface and after use, can be wiped clean for ease of drying and reuse.

Smart FlexiPad comes in two versions; **Audible Sounder only** and **Wi-Fi Only**.

Applications:

Can be installed under dishwashers, washing machines, sinks, baths, and showers.

Detection:

Activates with any conductive liquid, once dry can be returned to use.

Construction:

Tough, flexible plastic sheet with bonded "carbon loaded" detection tracks.

Fixing:

The sensor can lay loose. The sounder or Wi-Fi transmitter is surface mounted and is supplied with double sided adhesive strip.



Dimensions:

Sensor – 400mm x 300mm x 1mm
(8mm at connection point)

The Sounder – 98mm x 40mm x 23mm

Sounder enclosure – 98mm x 4mm x 23mm

Wi-Fi enclosure – 70mm x 25mm x 20mm

Adhesive Pad – 3M Double Sided, Thickness 2mm

Power:

Audible only version uses a standard PP3 9v battery.

Wi-Fi version uses 2 x AAA batteries

(with a low battery warning)

Battery life expectancy – 1 year +

Alerts:

Discoverable Wi-Fi Connects to all popular Smart home APPs.

Notifications can be set in your smart home App under the device options page. The options menu has both notification and battery monitor notification settings. Audible version has local 90dB that sounds for as long as the sensor is in contact with water.

There are two ways to silence the sounder –

Remove the battery - by accessing the battery compartment slider, on the underside of the enclosure. Dry the mat, ensuring that it is completely dry, then re-fit the battery.

Or simply dry the mat completely.